

# Material and care instructions for Oiled wood

All wood used in Rusta garden furniture comes from well-managed, FSC-certified plantations. FSC represents responsible forestry with regard to people and the environment.

Wood is a natural material and its appearance can change over time. Regular maintenance will prolong the life of the product.

## Care instructions

- If the furniture has been in storage for some time, it should be oiled before being used again. Then treat the furniture a couple of times a year or when necessary. To properly protect the furniture, it should always be oiled before winter storage.
- Clean the furniture at regular intervals. Use a mild detergent, such as soap, and water. If the furniture is exposed to algae, it can be washed outdoors using the Reflekt Målartvätt cleaning product. Always clean the furniture before storing it for the winter.
- Retighten the screw fittings twice a season to ensure the furniture retains its stability.
- Never place hot objects, such as pans and plates, directly on the table. Protect the wood by using a table mat. Wipe off any spilled liquid and food immediately, especially strongly coloured liquids, such as coffee and wine.
- Place the furniture under cover when not in use during the summer. Use furniture covers as protection against rain and dirt. If the furniture is left exposed, tilt it so that the water easily runs off and wipe it once it stops raining, particularly any flat wooden surfaces.